

Additional safe digging information


The illustration below provides some guidance on where written consent is required before any ground disturbance. If you are unsure if your planned activity requires a locate request or written consent, please contact Enbridge.

Activities that DO NOT require consent

- (A) Crossing a pipeline while traveling off-road with an off-highway or private passenger vehicle up to 3/4 ton (as defined by the Traffic Safety Act)
- (B) Cultivation to a depth of less than 45 cm (e.g. cultivating agricultural crops) or ground disturbance to a depth of less than 30 cm (e.g. gardening)
- (C) Operating vehicles or mobile equipment across a pipeline which are used for normal farming operations

Activities that DO require consent

- (D) Ground disturbance depths of 30 cm or more (trenching, plowing, drilling, tunnelling, augering, backfilling, blasting, peat removing, quarrying, clearing, land leveling, topsoil stripping, deep tilling, subsoiling and grading)
- (E) Installing/constructing a fence, retaining wall or structure
- (F) Installing facilities on, along, under or across the pipeline controlled area
- (G) Landscaping, tree/shrub planting, clearing and removing stumps
- (H) Constructing roads, paving, parking areas, driveways and ditches
- (I) Stockpiling materials
- (J) Drainage or irrigation systems (including dykes, ditches and culverts)
- (K) Crossing a pipeline while not on an upgraded and traveled portion of an established highway or public road with vehicles or mobile equipment
- (L) Using explosives to blast within the 30 m controlled area. A detailed blasting plan must be filed with Enbridge.



> Alberta Energy Regulator (AER) Pipelines in Enbridge's Athabasca system are provincially regulated by the AER and must comply with specific pipeline standards and regulations. As part of AER regulations, no ground disturbance activities may be undertaken without the approval of the pipeline company. In addition to the ROW where pipelines are located, the AER has established a 30 m controlled area, measured perpendicularly on each side from the centreline of the pipeline, in each direction, to protect you, the environment and the pipeline.

Safety checklist

If you are planning to construct a facility or conduct a ground disturbance activity near a pipeline, please follow this safety check list:

- 1. Plan your activity.** Identify the location of your work, making sure to look for pipeline warning signs or pipeline marker posts.
- 2. Contact Enbridge to obtain written consent.** Contact us to obtain our guidelines for constructing a facility, conducting a ground disturbance activity or vehicle crossing near pipelines.
- 3. Contact Utility Safety Partners** (formerly Alberta One-Call) at least three working days before planned work.
- 4. Be on site** when underground facilities are being located to be sure you understand the meaning of the markings.
- 5. Review AER requirements.** Confirm that any persons or companies hired to do work on your behalf, such as contractors, are aware of the necessary obligations.
- 6. Follow all instructions** provided in the authorization including hand exposing or vacuum excavating the pipe before mechanical excavations.
- 7. Call Enbridge** at least one full working day before you backfill over any exposed pipeline. An Enbridge representative must be on site during backfill.
- 8. Immediately notify Enbridge** if you come into contact with the pipe or its coating.

Always remember to dig with CARE

C all or **Click Before You Dig.**

A llow required time for markings.

Provide adequate notice prior to starting your excavation. This provides time for companies to accurately locate and mark their facilities in your dig area.

R espect the marks.

Before you begin your excavation, walk through the site to familiarize yourself with the markings and the location of buried facilities. Confirm that all companies have responded to you indicating they have marked your dig area.



E xcavate carefully.

It is important that you take a proactive approach to safety not only for yourself, but also for your community by initiating the one-call process and excavating with CARE.

Know the code

Colour codes are extremely important. While not all facility owners have adopted the same coding system, it remains very important that you confirm colour markings when you see them.

APWA (American Public Works Association) Uniform Color Code

-  White – Proposed Excavation
-  Pink – Temporary Survey Markings
-  Red – Electric Power Lines, Cables, Conduit and Lighting Cables
-  Yellow – Gas, Oil, Petroleum or Gaseous Materials
-  Orange – Communication, Alarm or Signal Lines
-  Blue – Potable Water
-  Purple – Reclaimed Water, Irrigation and Slurry Lines
-  Green – Sewer and Drain Lines